

EMERGENCY RADIO CALL PROCEDURES

DSC RADIO

1. Make sure radio is on
2. Lift cover
3. Press DISTRESS button for 5 seconds and release



▶ **HAVE ALL PEOPLE PUT ON LIFE JACKETS**

EMERGENCY RADIO CALL PROCEDURES

NON DSC RADIO

1. Change to CHANNEL 16
2. Press and hold TRANSMIT button
3. Clearly say: **"MAYDAY, MAYDAY, MAYDAY"**
4. Also give:
 - vessel name/description
 - position/location
 - nature of emergency
 - number of people on board
5. Release TRANSMIT button
6. Wait 30 seconds—if no response, repeat **"MAYDAY"** call



▶ **HAVE ALL PEOPLE PUT ON LIFE JACKETS**